Dancar Scandinavia

LED resistor to avoid lamp failure.
Make fitting of resistor in parallel
to the LED strap as shown.

LED modstanden modvirker lampefejl.
Monter modstanden parallelt med
LED strap som vist.

(+54) light

150 ohm

Gnd

LED strap